


Installation Instruction

Update of Speedlink driver for 64-bit


1. Extract the zip file
2. Double Click on Setup.exe
3. Click Next



4. Click Install



5. Click Finish



TTO/16-04-10